



southpaw enterprises, inc.[®]

Instruction Sheet

Helicopter Swing 120170

Store these instructions along with the enclosed maintenance checklist in a safe place. You may also access them on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location. The Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

Warning: Failure to properly install a forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the forged steel eyebolt, please contact Southpaw Enterprises

MATERIALS LIST:

- | | |
|-----------------------|-----------------------------------|
| 1 - Helicopter Swing | 1 - Safety Snap Instruction Sheet |
| 1 - Instruction Sheet | 1 - Maintenance Checklist |
| 3 - Safety Snaps | |

INSTRUCTIONS FOR USE:

- Attach your Helicopter Swing to your support eye bolts with the Safety Snaps provided. The four ropes near the head and chest point will suspend from one eyebolt, while the two ropes near the foot of the swing will suspend from the second eyebolt.
- To suspend your Helicopter Swing from two points, suspension points must be between 3 feet and 4 feet apart.
- Use the Southpaw Height Adjuster (# 5000) to raise or lower the Helicopter Swing to the appropriate height.

WEIGHT LIMIT: 200 lbs.

SPACE REQUIREMENTS:

Height requirement minimum of 8 feet.

Use caution to keep a minimum of 6 foot clear distance from walls and other obstacles.

MAINTENANCE CHECKLIST:

The following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Check seams for rips or tears. If rips or tears are found, discontinue use immediately until repaired.
- Check ropes for loose or missing splice locks (a splice lock is the metal clip near the end of the ropes). If loose or missing splice locks are found, discontinue use until repaired.
- Check Safety Snaps for wear (see Safety Snap Instruction Sheet).

MATTING PRECAUTIONS:

- Always use appropriate matting.
- Crash mats and wall mats must be used with all hanging equipment.

CLEANING INSTRUCTIONS:

Check with your infectious disease department before using these procedures.

- Check for client allergies first.
- Clean with a damp cloth. Air dry.
- *DO NOT MACHINE WASH.*

STORAGE PROCEDURES:

- Store out of direct sunlight.
- Store where not accessible by clients without proper supervision.

CAUTION

- ◆ **Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.**
- ◆ **Floor mats of proper thickness should be positioned properly under and around all suspended equipment.**

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.



If you have any questions or comments, please call or write
Southpaw Enterprises, Inc.
P.O. Box 1047, Dayton, Ohio 45401 -1047
Toll Free - (800) 228-1698
Come see us on the World Wide Web at <http://southpawenterprises.com>